

This Service bulletin has been produced in accordance with approved Alternative Procedures to DOA EASA.AP356.
Technical data has been approved by EASA under Approval No.:

☐ INFORMATION☐ RECOMMENDED☒ **MANDATORY**

3.8.4 Rescue system

Activation of rescue system:

1. Switch of the ignition to stop the engine.
2. Lift off the emergency system actuator protector (1) (fig. 3.8.3-1).
3. Strongly pull the handle of rescue system.
4. Protect your head by hands.




Fig. 3.8.4-1 Emergency system actuator protector

For other information regarding operation and handling with rescue system Magnum 601 S-LSA refer to the Manual for Mounting and Use - Rescue Ballistic Parachute Systems Series Magnum.