

[illegible]

0.2 LIST OF EFFECTIVE PAGES

Section	Page	Date	Section	Page	Date
0	1	25.02.2014	2	5	25.02.2014
	2	16.03.2015		6	25.02.2014
	3	16.03.2015		7	25.02.2014
	4	25.02.2014		8	25.02.2014
	5	25.02.2014		9	25.02.2014
1				10	25.02.2014
	1	25.02.2014		11	25.02.2014
	2	25.02.2014		12	25.02.2014
	3	25.02.2014			
	4	25.02.2014	3	1	25.02.2014
	5	25.02.2014		2	25.02.2014
	6	25.02.2014		3	25.02.2014
	7	25.02.2014		4	25.02.2014
	8	25.02.2014		5	25.02.2014
	9	25.02.2014		6	25.02.2014
	10	25.02.2014		7	25.02.2014
	11	25.02.2014		8	25.02.2014
	12	25.02.2014		9	25.02.2014
	13	25.02.2014		10	25.02.2014
	14	25.02.2014		11	25.02.2014
	15	25.02.2014		12	25.02.2014
	16	25.02.2014		13	25.02.2014
	17	25.02.2014		14	25.02.2014
	18	16.03.2015		15	25.02.2014
	19	25.02.2014		16	25.02.2014
	20	25.02.2014		17	25.02.2014
	21	25.02.2014		18	25.02.2014
	22	25.02.2014		19	25.02.2014
	23	25.02.2014		20	25.02.2014
	24	25.02.2014		21	25.02.2014
	25	25.02.2014		22	25.02.2014
	26	25.02.2014		23	25.02.2014
	27	25.02.2014		24	25.02.2014
	28	25.02.2014		25	25.02.2014
	29	25.02.2014		26	25.02.2014
	30	25.02.2014			
	31	25.02.2014	4	1	25.02.2014
	32	25.02.2014		2	25.02.2014
				3	25.02.2014
				4	25.02.2014
2	1	25.02.2014		5	25.02.2014
	2	25.02.2014		6	25.02.2014
	3	25.02.2014			
	4	25.02.2014			

Powerplant instrument markings and their colour code significance are shown below:

Instrument	Unit	Red Line Minimum Limit	Green Arc Normal Operating	Yellow Arc Caution Range	Red Line Maximum Limit
Tachometer	RPM	1400	1800 - 5500	5500 - 5800	5800
Manifold pressure	inHg	-	10,0 – 35,4 ³	35,4 – 39,9 ³	39,9 ³
Oil temperature indicator	°C	50	90 - 110	50 - 90 110 – 130 ^{1,3} 110 – 140 ²	130 ^{1,3} 140 ²
Coolant temperature indicator	°C	-	90 – 110	50 – 90 110 – 120	120
Cylinder head temperature indicator	°C	-	-	-	135 ^{1,3} 150 ²
Fuel pressure indicator	bar	0,15	0,20 - 0,35	0,15 - 0,20 0,35 - 0,40	0,40
Oil pressure indicator	bar	0,8	2,0 - 5,0	0,8 - 2,0 5,0 - 7,0	7,0
Fuel quantity indicator	l	Red light annunciator will be illuminated with the remaining 7 litres of fuel in the fuel tank.			

- 1) Indication is valid for ROTAX 912 S2 engine
 2) Indication is valid for ROTAX 912 UL engine
 3) Indication is valid for ROTAX 914 F/UL engine

1.6.8.4. Avionics

The following avionics are mounted in the airplane: radios and intercom. This equipment must be connected with the headphones and with the antenna. The airplane might be equipped with other instruments (GPS, transponder, or board computer). The flight and navigation instruments are mounted as an option of the customer (but with respect to the weight limitation of the aircraft). Refer to the Manuals supplied with above mentioned instruments for right operation of the instruments and for more details.

1.6.8.5. Rescue system

The airplane can be equipped with parachute rescue system MAGNUM 601 S-LSA from the company STRATOS 07 spol. s r. o. as miscellaneous equipment. This rescue system is designed for the aircraft with maximum weight up to 620 kg and with maximum speed of using 290 km/h. The area of parachute is 130 m². The descent rate with opened parachute is 7,0 m/sec. The container dimension is 430x210x250 mm and the total weight is 12,9 kg. Rocket motor is Magnum 600 A with total thrust pulse 0,539 kNs. The life time of the rescue system is 18 years with the repacking interval is 6 years.



Fig. 10. Rescue system MAGNUM 601 S-LSA