

0.2 LIST OF EFFECTIVE PAGES

Section	Page	Date	Section	Page	Date
0	1	29.04.2013	2	5	29.04.2013
	2	16.03.2015		6	29.04.2013
	3	16.03.2015		7	29.04.2013
	4	29.04.2013		8	29.04.2013
	5	29.04.2013		9	29.04.2013
1				10	29.04.2013
	1	29.04.2013		11	29.04.2013
	2	29.04.2013		12	29.04.2013
	3	29.04.2013		14	29.04.2013
	4	29.04.2013			
	5	29.04.2013	3	1	29.04.2013
	6	29.04.2013		2	29.04.2013
	7	29.04.2013		3	29.04.2013
	8	29.04.2013		4	29.04.2013
	9	29.04.2013		5	29.04.2013
	10	29.04.2013		6	29.04.2013
	11	29.04.2013		7	29.04.2013
	12	29.04.2013		8	29.04.2013
	13	29.04.2013		9	29.04.2013
	14	29.04.2013		10	29.04.2013
	15	29.04.2013		11	29.04.2013
	16	29.04.2013		12	29.04.2013
	17	29.04.2013		13	29.04.2013
	18	16.03.2015		14	29.04.2013
	19	29.04.2013		15	29.04.2013
	20	29.04.2013		16	29.04.2013
	21	29.04.2013		17	29.04.2013
	22	29.04.2013		18	29.04.2013
	23	29.04.2013		19	29.04.2013
	24	29.04.2013		20	29.04.2013
	25	29.04.2013		21	29.04.2013
	26	29.04.2013		22	29.04.2013
	27	29.04.2013		23	29.04.2013
	28	29.04.2013		24	29.04.2013
	29	29.04.2013		25	29.04.2013
	30	29.04.2013		26	29.04.2013
	31	29.04.2013			
	32	29.04.2013	4	1	29.04.2013
				2	29.04.2013
2	1	29.04.2013		3	29.04.2013
	2	29.04.2013		4	29.04.2013
	3	29.04.2013		5	29.04.2013
	4	29.04.2013		6	29.04.2013

Powerplant instrument markings and their colour code significance are shown below:

Instrument	Unit	Red Line Minimum Limit	Green Arc Normal Operating	Yellow Arc Caution Range	Red Line Maximum Limit
Tachometer	RPM	1400	1800 - 5500	5500 - 5800	5800
Manifold pressure	inHg	-	10,0 – 35,4 ³	35,4 – 39,9 ³	39,9 ³
Oil temperature indicator	°C	50	90 - 110	50 - 90 110 - 130 ^{2,3} 110 - 140 ¹	140 ¹ 130 ^{2,3}
Coolant temperature indicator	°C	-	90 – 110	50 – 90 110 – 120	120
Cylinder head temperature indicator	°C	-	-	-	150 ¹ 135 ^{2,3}
Fuel pressure indicator	bar	0,15	0,20 - 0,35 ^{1,2} 0,25 - 1,00 ³	0,15 - 0,20 ^{1,2} 0,35 - 0,40 ^{1,2} 0,15 - 0,25 ³ 1,00 - 1,50 ³	0,40 ^{1,2} 1,50 ³
Oil pressure indicator	bar	0,8	2,0 - 5,0	0,8 - 2,0 5,0 - 7,0	7,0
Fuel quantity indicator	l	Red light annunciator will be illuminated with the remaining 7 litres of fuel in the fuel tank.			

1) Indication is valid for ROTAX 912 A/F/UL engine

2) Indication is valid for ROTAX 912 S/ULS engine

3) Indication is valid for ROTAX 914 F/UL engine

1.6.8.4. Avionics

The following avionics are mounted in the airplane: radios and intercom. This equipment must be connected with the headphones and with the antenna. The airplane might be equipped with other instruments (GPS, transponder, or board computer). The flight and navigation instruments are mounted as an option of the customer (but with respect to the weight limitation of the aircraft). Refer to the Manuals supplied with above mentioned instruments for right operation of the instruments and for more details.

1.6.8.5. Rescue system

The airplane can be equipped with parachute rescue system MAGNUM 601 S-LSA from the company STRATOS 07 spol. s r. o. as miscellaneous equipment. This rescue system is designed for the aircraft with maximum weight up to 620 kg and with maximum speed of using 157 knots. The area of parachute is 130 m². The descent rate with opened parachute is 7,0 m/sec. The container dimension is 430x210x250 mm and the total weight is 12,9 kg. Rocket motor is Magnum 600 A with total thrust pulse 0,539 kNs. The life time of the rescue system is 18 years with the repacking interval is 6 years.



Fig. 10. Rescue system MAGNUM 601 S-LSA